

GAFNER manure and compost spreader

SPARE PARTS LIST

Supplementary sheet central lubrication

copyright ©

The publisher of these customer documents is GAFNER Maschinenbau AG,
CH-8637 Laupen-Wald (Tel. 055 246 34 15 / FAX 055 246 51 70)


All rights, in particular the right of reproduction and distribution as well as the
Translation, are reserved. No part of this work may be reproduced in any form
(print, photocopy, microfilm or any other process) without written permission
reproduced or stored, processed,
reproduced or distributed.

Technical changes



GAFNER reserves the right to make changes at any time without prior notice.
to the product or this document.

Version: 2024

Central lubrication



X: Aufbau = Pos. 4
Anhänger = Pos. 3



Central lubrication

Pos.	Order No.	Order text	Dimension
1	700.00.335	Double lubrication block	
2	700.00.337	Single lubrication block	
3	700.00.334	Straight screw connection	G1/8"
4	700.00.625	Screw connection angle 90°	G1/8"
5	700.00.624	Screw connection angle 90°	M6
6	700.00.340	cable clamp	
7	110.02.010	Bearing housing round with hole for screw connection	
8	110.04.008	Drilling screw with lens head	ø6.3x19
9	603.04.012	hexagon screw	M5x25
10	700.00.338	Pressure pipe polyamide	ø6mm
11	110.04.011	Straight screw connection with internal thread	M6
12	110.04.012	90° angle screw connection with internal thread	M6
13	700.00.405	Grease nipple	M6