

GAFNER Manure and Compost Spreader

SPARE PARTS LIST

2.46 - 3.16 vario roto mounted

Copyright ©

This customer documentation is published by GAFNER Maschinenbau AG,
CH-8637 Laupen-Wald (Tel. 055 246 34 15 / FAX 055 246 51 70)
All rights reserved, particularly the rights of reproduction, distribution and translation.
No part of this work may be reproduced in any form (printing,
photocopying, microfilm or any other process) or stored,
processed, reproduced or distributed using electronic systems,
without written authorisation.

Technical modifications

GAFNER reserves the right to make technical modifications
to the product or to this document at any time without separate notification.

Table of contents

Chapter

- 1 Drive unit
- 2 Star-shaped rotor - planetary gearbox
- 3 Spreading rotor - spreading flap
- 4 Scraper floor
- 4a Deflection
- 4b Slide
- 6 Hydraulics - actuation elements
 - Hydraulic hoses
- 6 Ha Hydraulic unit
- 7 Tank
- 8 Spreading housing
- 9 Swivel mechanism - Roto
- 11 Rear lights and supports
- 12 Mounting elements for truck
- 13 Self-adhesive signs

Ordering example for spare parts

Gafner type: e.g. type 2.46 H VARIO


Chassis number: e.g. No. 10566

Spare part number: e.g. No. 201.01.100

Order text: e.g. Drive shaft VARIO mounted model


Quantity: e.g. 1 pc.

- 1 -



Drive unit


Pos.	Order no.	Order text
1	201.01.100	Drive shaft mounted model
5	000.02.010	Flanged bearing oval D 35
5	001.01.005	Bearing insert for D 35
17	000.01.017	Chain rider 3/4"
18	601.01.045	Hexagon screw M 12x55
19	301.01.015	Spacer plate
20	000.01.020	Perforated plate
21	000.01.021	Slider for tensioner M 12 - thread
22	000.01.022	Threaded rod M 12 (specify length)
23	000.01.023	Compression spring 3.2/19.2x59
33	204.01.033	Roller chain 3/4" ASA 60 127 links
34	207.01.034	Roller chain 3/4" ASA 60 98 links (drive mounted off-centre)
	202.01.034	Roller chain 3/4" ASA 60 97 links (drive mounted centrally)
	004.01.034	Chain lock straight 3/4"
	005.01.034	Chain lock bent 3/4"
35	000.02.032	Hexagon nut M 12
37	000.03.018	Locknut M 12
39	000.02.031	Washer M 12
40	000.02.030	Hexagon screw M 12x30
41	000.01.052	Shaft extension extendable
43	000.03.026	Pillow block D 35
43	001.01.005	Bearing insert for D 35
45	201.01.451	PTO shaft guard plate mounted
60	000.01.060	PTO shaft w. guard overall length 75 cm with shear bolts
60	000.02.060	PTO shaft w. guard overall length 108 cm
60	000.03.060	PTO shaft w. guard overall length 140 cm
	000.03.065	Shear bolt hexagon M 8x50 qual. 10.9 for PTO shaft
	000.03.066	Shear bolt hexagon M10x50 qual. 8.8 for PTO shaft
	000.04.060	Shear bolt hexagon M 8x50 qual. 12.9 for PTO shaft



Star-shaped rotor planetary gear


Pos.	Order no.	Order text	
1	000.02.001	Hollow shaft	
1-5	000.02.100	Hollow shaft compl. (Ball bearing, Star rotor bearing, Felt seal)	
2	000.02.002	Star-shaped rotor bearing without ball bearing	
	301.01.018	Felt seal	
3	000.02.003	Ball bearing 6016	
4	000.02.004	Circlip A 80	
5	000.02.005	Ball bearing 6007	
6	000.02.006	Feather key 10/8x56	
7	001.02.700	Drive shaft with sprocket 1" Z 12	
8	000.02.008	Feather key 10/8x45	
9	777.01.136	Sprocket plate 3/4" Z 81	
9a	201.02.900	Hub screwable for sprocket plate (top)	
10	201.02.010	Flanged bearing round D 35	
	001.01.005	Bearing insert D 35	
	210.08.217	Rotating ring for V-belt box roto	
	210.08.218	Hexagon socket head screw M4x8 roto	
	778.06.005	Retaining ring V-belt box roto	
11	000.02.011	Sprocket 3/4" Z 25	
	001.02.110	Sprocket pair 3/4" Z 25 3/8" Z60 f. machine with hydraulic unit	
13	150.01.001	Spacer ring	
14	002.02.014	V-belt pulley SPB-315-2 w. Taperlock (2-groove)	
15	202.02.015	Star-shaped rotor disc	
	777.36.002	Star-shaped rotor disc milling planetary gear	
16		Feed bucket low right	no longer in the product range
	001.02.160	Feed bucket low right compl. with rubber	
17		Feed bucket high left (mounted model)	no longer in the product range
	001.02.170	Feed bucket high left compl. with rubber (mounted model)	
18		Feed bucket low left	no longer in the product range
	001.02.180	Feed bucket low left compl. with rubber	
19	000.02.019	Counterweight	
20	201.02.200	Planetary box	
	202.02.200	Planetary box compl. (box,bearing,shaft,hub,cutter)	
	005.02.200	Planetary box milling planetary gear	
	000.02.050	Planetary box tensioner	
21	202.02.210	Planetary star 4-arm	
	203.02.211	Hub for milling planetary star screwable ø 30	
	777.36.000	Milling planetary star without hub	
22	201.02.022	Planetary cutters straight and ground	
	211.02.220	Planetary cutter straight and ground (1 set of 4 w/o screws)	
	203.02.022	Screw set for straight planetary cutters (4xM16+nuts 4xM8)	
	221.02.022	Milling tooth	
	221.02.220	Milling tooth (set of 6 pcs. w/o scr.)	
	233.02.210	Milling planetary star compl. with hub, teeth, screws	
23	202.02.230	Planetary shaft 1" Z11	
	203.02.230	Planetary shaft 1" Z19 for milling planetary gear	
24	000.02.024	Bronze bearing	
25	000.02.025	Feather key 8/7x36	

- 2 -




Star-shaped rotor planetary gear

Pos.	Order no.	Order text
26	000.02.026	Circlip A 30
27	202.02.027	Continuous roller chain 1" ASA 80 34 links
	203.02.027	Continuous roller chain 1" ASA 80 38 links Milling planetary gear
28	001.02.280	Lubrication pipe
29	000.02.029	Lubrication nipple
30	000.02.030	Hexagon screw M 12x30
31	000.02.031	Washer M 12
32	000.02.032	Hexagon nut M 12
33	000.03.018	Hexagon locknut M 12
34	000.02.034	Hexagon screw M 12x20
35	000.03.035	Hexagon screw M 12x25
36	201.12.032	Hexagon screw M 16x35 + nut + washer
	000.02.480	Shear bolt f. straight planetary cutter M 8x20 + locknut
37	000.02.037	Hexagon screw M 12x40
38	000.02.038	Flexible rubber plate
39	000.02.039	Counter-plate bent
40	000.02.040	Lock screw M 8x35
41	000.02.041	Locknut M 8
44	000.05.005	Circlip A 35
45	302.03.014	Hexagon screw M 10x25
46	003.03.102	Washer M 10
47	201.04.165	Hexagon nut M 10




Spreading rotor spreading flap

Pos.	Order no.	Order text
1	102.03.100	Deflector VARIO and ROTO
2	101.03.002	Mounting shaft D 15 for telescopic plate VARIO and ROTO
3	101.03.003	Hexagon screw M10x60
4	601.04.006	Splint 5x32
5	000.01.021	Slider for tensioner M12
6	102.03.902	Axle for tensioner
7	000.01.022	Threaded rod M12 (specify length)
8	000.01.023	Compression spring for tensioner 3.2/19.2x59
9	102.03.900	V-belt tensioner alu with ball bearing
10	101.03.010	Hexagon screw M 12x 65
11	301.01.015	Spacer plate
12	000.02.005	Deep groove ball bearing 6007 2RS
13	001.03.013	Compression springs 5/25x125
14	000.03.014	Eyebolt M 10x140
15	303.03.007	Body disc M 12
16	000.02.032	Hexagon nut M 12
17	000.03.017	Hexagon screw M 12x40 qual. 10.9
18	000.03.018	Locknut M 12
19	000.02.031	Washer M 12
20	000.03.020	Toothed washer M 12
21a	000.03.021	Spreading tines normal
21b	002.03.021	Wide spreading tines
	003.03.210	Spreading tines 1 set of 12 pcs. incl. screws
	033.03.210	Spreading tines 1 set of 12 pcs. without screws
	002.03.210	Wide spreading tines 1 set of 8 + 4 pcs. incl. screws
	022.03.210	Wide spreading tines 1 set of 8 + 4 pcs. without screws
22	003.03.101	Locknut M 10
23	003.03.102	Washer M 10
24	102.03.240	Spreading rotor without tines
25	000.02.006	Feather key 10/8x56
	000.02.008	Feather key 10/8x45
26	000.03.026	Pillow block D 35
	001.01.005	Bearing insert for SW 35
27a	202.03.027	V-belt pulley SPB-160-2 w. Taperlock (2-groove)
27b	102.03.027	Taperlock bush 2012 Ø35
28a	000.03.029	V-belt pulley SPA-125-1 w. Taperlock (1-groove)
28b	102.03.029	Taperlock bush 1610 Ø35
29a	000.03.032	V-belt pulley SPA-85-1 w. Taperlock (1-groove)
29b	102.03.032	Taperlock bush 1210 Ø25
30	000.03.300	ROSTA belt tensioner compl.
31	102.03.310	ROSTA tensioner Ø 30 with ball bearing
32	210.08.009	Guard plate flanged bearing



Spreading rotor spreading flap


Pos.	Order no.	Order text
33	210.08.010	Guard plate bent
34	000.03.034	Pillow block D 25
	001.03.034	Bearing insert for SW 25
35	102.03.350	Mini rotor
36	000.03.036	Feather key 8/7x28
39	101.03.039	V-belt for mini rotor 13 x 825 Li
40	103.03.040	V-belt for spreading rotor SPB 2360 LW
	103.03.041	Power belt 2/SPB-2360 LW
44	210.08.008	Bearing plate for rocker
45	201.03.045	Flanged bearing square D 35
	001.01.005	Bearing insert D 35
46	101.09.019	Flanged bearing oval D 25
	001.03.034	Bearing insert D 25
47	302.03.013	Hexagon screw M 10x12
50	211.03.500	Telescopic plate (without guide) f. VARIO
51	211.03.510	Telescopic plate (with guide) f. VARIO
	111.03.500	Connecting plate for deflector ROTO
52	201.03.052	Shaft 15x275
53	211.03.530	Adjustment rocker f. VARIO
	111.03.530	Adjustment rocker f. ROTO
54	201.03.540	Cylinder double acting f. VARIO
55	602.03.030	Hexagon screw M 16x60
56	601.08.022	Hexagon screw M 16x100
57	201.04.026	Hexagon locknut M 16



Scraper floor

Pos.	Order no.	Order text	
1	301.07.100	Base frame	
2	302.07.200	Additional frame	2.46
	303.07.200	Additional frame	2.66
	304.07.200	Additional frame	3.16
3	201.04.100	Feed shaft	ø 40
7	302.07.007	Mounting plate f. gearbox	
8	001.04.010	Scraper floor bar	
9	000.04.009	Flat bar stop	
10	302.07.010	Shackle	M 10
11	000.04.013	Round link chain member	15 links
12	301.07.012	Round link chain member	11 links
13	302.07.013	Round link chain member f. type 2.46	87 links
	401.04.015	Round link chain member f. type 2.66	99 links
	304.07.013	Round link chain member f. type 3.16	103 links
14	601.04.021	Planetary gearbox 2-stage without motor	
15	601.04.022	G-roller motor 100 cm ³ for above gearbox	
16	601.04.023	Gerotor for G-roller motor 100cm ³	
18	216.07.502	Hexagon screw	M 10 x 140
	601.04.029	Hexagon screw	M 10 x 150
19	000.02.030	Hexagon screw	M 12 x 30
21	000.02.031	Washer DIN 125 A	M 12
23	601.04.028	Hexagon locknut steel	M 10
24	003.03.101	Hexagon locknut	M 10
25	000.03.018	Hexagon locknut	M 12
27	000.04.002	Flanged bearing	ø 40
28	201.04.020	Rubber plate	
29	000.04.021	Fixing lug	
30	000.02.040	Lock screw incl. locknut	M 8 x 35


- 4a -



Deflection





Pos.	Order no.	Order text	
1	777.66.063	Deflection guard	
2	303.07.400	Clamping bar	
3	303.07.006	Deflection slider	
4	303.07.005	Finger guard deflection slider	
5	777.66.065	Lock washer	
6	000.04.009	Flat bar stop	
7	302.07.010	Shackle screwable	M 10
8	201.04.025	Compression spring	5 x 25 x87.5
9	000.02.041	Hexagon locknut	M 8
10	601.04.028	Hexagon locknut steel	M 10
11	201.04.026	Hexagon locknut	M 16
12	201.04.031	Hexagon screw	M 8 x 65
13	601.04.039	Hexagon screw	M 16 x 200
	302.07.410	Deflection complete	

- 4b -



Slide with shear support

Pos.	Order no.	Order text	
1	350.07.100	Slide	
2	357.07.200	Slide attachment	
3	301.07.300	Slide base	
4	106.07.400	Shear brace	
5	777.66.043	Limiter	
6	002.04.018	Plastic glide long	38 / 30 x 190
7	301.07.007	Roller nylon	ø 40 x 30
8	301.07.008	Spacer bush	ø 18/13 x 11
9	301.07.009	Spacer bush	ø 18/13 x 20
10	301.07.010	Spacer bush	ø 30/17 x 10
11	000.02.040	Lock screw	M 8 x 35
12	000.03.035	Hexagon screw	M 12 x 25
13	601.04.032	Hexagon screw	M 12 x 35
14	301.07.024	Hexagon screw	M 12 x 80
15	601.08.021	Hexagon screw	M 16 x 50
16	205.12.404	Hexagon screw	M 16 x 75
17	201.04.174	Washer heavy-duty	ø 8.4 / 20 x 2
18	301.07.018	Washer special	
19	000.02.031	Washer DIN 125 A	M 12
20	301.03.016	Washer VSM 13908	ø 13 / 28 x 4
21	201.12.031	Toothed washer	M 16
22	000.02.041	Hexagon locknut	M 8
23	000.02.032	Hexagon nut	M 12
24	000.03.018	Hexagon locknut	M 12
25	201.04.026	Hexagon locknut	M 16
26	700.00.347	Rubber ring	



Hydraulics - actuation elements

Pos.	Order no.	Order text
1	202.06.001	"Oil-Control" flow controller without screw connections
	202.06.003	Setting cone with adjustment knob
2	201.06.002	Holder f. flow controller and control block (mounted models)
3	201.06.003	Clamp bar
4	202.06.004	Control block 1x DA f. VARIO and ROTO w/o screw connections
5	201.09.033	Hydraulic accumulator without screw connection
6	500.06.014	Lever valve for accumulator (stroke limiter)
7	201.06.007	Support bracket for accumulator
8	201.06.008	Control block 2x DA with flow controller f. hydr.unit w/o screw connections


Hydraulic hoses

Order example

Overall length:	2900 mm
Connections:	1st side 0° / 2nd side 45°
from where to where?:	Coupling to feed
Machine type:	2.46 H VARIO
Chassis no.:	10'566
Truck type:	Muli 500


000.05.020	Hydraulic socket (female piece) with dust cap
000.05.021	Hydraulic connector (male piece) with dust cap

- 6 Ha -



Hydraulic unit on spreader


Pos.	Order no.	Order text
8	201.06.008	Control block 2x DA with flow controller f. hydr.unit w/o screw connections
11	201.06.002	Holder f. flow controller and control block (mounted models)
12	201.06.003	Clamp bar
12.1	201.06.004	Mounting plate for control block
13	201.06.130	Oil tank round f. VARIO
14	001.06.051	Filler cap compl.
15	201.06.015	Suction filter
16	201.06.016	Flange for suction filter
17	201.06.017	Reducing fitting 1" / 1/2"
18	201.06.018	Screw-in fitting GE 18 1/2"
19	201.06.019	Gear pump clockwise f. mounted spreader
20	201.06.020	Connection angle 1/2"
21	201.06.021	Allen screw for connection angle
22	201.06.022	Screw-in fitting GE 18 1/2"
23	201.06.023	Pump bracket f. VARIO
24	201.06.024	Guard plate for pump
25	000.06.015	Sprocket 3/8" Z17 conical
26	201.06.026	Roller chain 3/8" 123 links for VARIO with closing element
	204.06.026	Chain lock straight 3/8"
30	201.06.030	Hydraulic hose tank pump



Tank


Pos.	Order no.	Order text
3		Floor plates
	202.07.003	2.46
	203.07.003	2.66
	204.07.003	3.16
4		Side plates
	205.07.400	2.46
	206.07.400	2.66*
	207.07.400	3.16*
5	201.07.005	Access guard left in direction of travel
	202.07.005	Access guard right in direction of travel
6	201.07.006	Wood strips specify length and height
	202.07.006	Wood strips specify length and height
7	202.07.007	Crosspiece types 2.46 - 3.16
8	201.07.008	Wood strip angle

* Specify whether left or right in direction of travel




VARIO spreading housing

Pos.	Order no.	Order text
1	214.08.100	Spreading housing H-Vario 2.46 - 3.16
2	210.08.200	V-belt box
3	210.08.003	V-belt box guard
4	210.08.400	Cross bar top f. VARIO
5	210.08.005	Cross bar bottom f. VARIO
6	210.08.006	Box guard small f. VARIO
7	211.08.007	Box guard large
8	778.01.023	Bearing washer for rocker f. VARIO
9	214.08.900	Service cover
10	302.01.019	Hexagon screw M8x25
11	302.01.025	Washer M8
12	000.02.041	Locknut M8
13	601.03.033	Hexagon screw M10x20
14	302.03.014	Hexagon screw M10x25
15	000.06.055	Hexagon screw M10x35
16	003.03.102	Washer M10
17	003.03.101	Locknut M10
18	201.03.044	Hexagon socket countersunk head screw M12x30
19	000.02.034	Hexagon screw M12x20
20	000.02.031	Washer M12
21	000.02.032	Hexagon nut M12
22	000.03.018	Locknut M12




ROTO spreading housing

Pos.	Order no.	Order text
1	215.08.100	Roto ring 2.46 - 3.16
2	215.08.200	Spreading housing H-Roto 2.46 - 3.16
3	202.08.003	Arc segment steel direction of travel right 2.46 - 3.16
	203.08.003	Arc segment steel direction of travel left 2.46 - 3.16
4	202.08.004	Arc segment steel top 2.46 - 3.16
5	202.08.005	Sliding segment plastic direction of travel right 2.46 - 3.16
6	203.08.005	Sliding segment plastic direction of travel left 2.46 - 3.16
7	202.08.006	Sliding segment plastic top 2.46 - 3.16
8	202.08.006	Sliding segment plastic top 2.46 - 3.16
9	206.08.009	Spacer bush
10	206.08.010	Idler plastic
11	206.08.011	Axle for idler
12	206.08.012	Bearing segment inner 2.46 - 3.16
13	214.08.900	Service cover
14	215.08.140	Stator box 2.46 - 3.16 mounted
15	201.08.009	Bearing cross-piece top
16	210.08.005	Bearing cross-piece bottom
17	210.08.200	V-belt box 2.46 - 3.16 mounted
	210.08.217	Rotating ring for V-belt box
	210.08.218	Hexagon socket head screw M4x8
	778.06.005	Retaining ring V-belt box
18	206.08.018	Spacer plate
19	206.08.019	V-belt box guard small 2.46 - 3.16 mounted
20	210.08.003	V-belt box guard 2.46 - 3.16 mounted
21	210.08.006	Stator box guard top
22	211.08.007	Box guard




ROTO spreading housing

Pos.	Order no.	Order text
23	000.02.041	Locknut M8
24	302.01.025	Washer M8
25	302.01.019	Hexagon screw M8x25
26	003.03.101	Locknut M10
27	003.03.102	Washer M10
28	601.03.033	Hexagon screw M10x20
29	601.03.033	Hexagon screw M10x20
30	000.06.055	Hexagon screw M10x35
31	000.02.031	Washer M12
32	301.03.016	Washer M12 x 4mm
33	303.03.007	Body disc M12
34	000.02.034	Hexagon screws M12x20
35	000.02.030	Hexagon screws M12x30
36	000.02.037	Hexagon screws M12x40
37	201.03.043	Hexagon screws M12x50
38	601.01.045	Hexagon screws M12x55
39	201.03.041	Hexagon screws M12x45
40	101.03.010	Hexagon screws M12x65
41	201.03.044	Hexagon socket countersunk head screw M12x30
42	000.03.018	Locknut M 12



Swivel mechanism - Roto

Pos.	Order no.	Order text
1	105.09.001	Roller chain 5/8" nickel-plated 201 links
2	101.09.002	Chain lock straight 5/8" nickel-plated
3	101.09.003	Chain tensioner
4	101.09.004	Chain latch
5	103.09.005	Chain guide rollers plastic
6	103.09.006	Axle for chain guide roller
7	103.09.007	Roto drive bridge
8	103.09.800	Shaft with sprocket 5/8" Z10 2.46 - 3.16
9	103.09.009	Roto drive
9a	103.09.010	Torque support
10	101.09.023	Worm gear
11	101.09.022	Aluminium flange
12	101.09.020	Hydraulic motor 8 cm ³
13	101.09.021	Feather key 5x5x16
14	700.00.105	Screw connections GE 12 L
15	000.02.025	Feather key 8x7x36
16	201.04.275	Allen screw M 6 x 12
17	201.04.274	Hexagon screw M6 x 12
18	601.03.032	Hexagon screw M6 x 25
19	601.03.031	Ribbed washer M6
20	201.04.277	Allen screw M8 x 12
21	201.04.278	Socket head countersunk screw M8 x 20
22	303.03.008	Body disc M8
23	000.02.034	Hexagon screw M12 x 20
24	000.02.031	Washer M12
25	000.03.018	Hexagon locknut M 12
26	602.03.030	Hexagon screw M16 x 60
27	101.06.016	Washer M16
28	201.04.026	Hexagon locknut M16
29	101.09.103	Compression spring for chain tensioner
30	302.01.033	Spacer M12













Rear lights and supports



Pos.	Order no.	Order text	
1	103.11.100	Lighting holder mounted spreader (without lamp holder)	
2	001.11.200	Lamp holder right	
3	001.11.300	Lamp holder left	
4	000.11.004	Socket 71/7	
5	103.10.010	Rear light complete FP 10 AJ.BA	
	104.10.010	Glass for rear light FP 10 AJBA	
6	000.11.006	Reflector round red	
11	500.11.003	Support foot for mounted spreader without cross tube	
12	500.11.650	Cross tube 60/60/1050 straight for support foot	
	500.11.550	Cross tube 60/60x420 straight for support foot	
		Spindle for portal support	no longer in the product range

Mounting elements for truck

-12-

No	TRANSPORTER	VORN	MITTE	HINTEN
1	AEBI	 1 x		 1 x li 1 x re
2	AEBI TP/VT 410/420.... Kombi TP98 / 420	 1 x		 1 x li 1 x re
3	BUCHER 1800 Granit BUCHER Caron	 2 x		 1 x li 1 x re
4	BUCHER Zenit 4000	 1 x li 1 x re		 1 x li 1 x re
5	LINDNER Unitrac LINDNER (m. Verdrehdämpfer)	 1 x li 1 x re	 2 x	 1 x li 1 x re
6	LINDNER Unitrac (tief)	 1 x li 1 x re	 2 x	 1 x li 1 x re
7	LINDNER 3500 bis Jg.85	 2 x	 2 x	 2 x
8	LINDNER 3500 ab Jg.85	 1 x li 1 x re	 1 x li 1 x re	 1 x li 1 x re
9	MULI Typ 30/33/50 Typ 400 bis 600 Typ 440 bis 970	 2 x		 2 x
10	MULI gefederte Hinterachse	 2 x		 2 x
11	MULI Typ 40	 2 x	 2 x	 2 x
12	RAPID AC 1350/1750 AC 1900 / AC 2500 LINDNER 3500 Lüönd Chasse	 1 x li 1 x re	 1 x li 1 x re	 1 x li 1 x re
13	RAPID AC 1400/1800 SCHILTRAC 9036	 2 x	 2 x	 1 x li 1 x re
14	RAPID AC 1800-26 AC 2000-26 AC 2500-28/30 AC 3000-28/30	 2 x		 2 x
15	SCHILTRAC 432 bis 9075 SCHILTER 3500 CARARO T80	 1 x li 1 x re	 1 x li 1 x re	 2 x
16	SCHILTER 1300 alt SCHILTER 1600	 2 x	 2 x	 2 x
17	SCHILTER 1300 neu SCHILTER 2200	 2 x	 2 x	 2 x
18	SCHILTER 1800	 2 x	 2 x	 2 x

Mounting elements for truck

No	TRANSPORTER	VORN	MITTE	HINTEN
19	Caron Typ C 40/48/52/55/63 Caron kuzer Radstand	 2 x  1 x li  1 x re	 2 x	 2 x
20	Caron Typ CT/CTK/CTM/CTS Serie 900	 1 x li  1 x re	 2 x	 2 x

30-32		   
-------	--	---

Mounting elements for truck

Pos.	Order no.	Order text	
1	201.12.100	AEBI - Mounting elements	Set incl. fixing
	202.12.100	AEBI - Mounting elements	Set without fixing
	203.12.100	AEBI - Cross bar front	
	204.12.100	AEBI - Upper part rear left	
	205.12.100	AEBI - Upper part rear right	
2	201.12.165	AEBI TP + VT 98/450 comb. - Mounting elements	Set incl. fixing
	202.12.165	AEBI TP + VT 98/450 comb. - Mounting elements	Set without fixing
	203.12.165	AEBI TP + VT 98/450 comb. - Cross bar front	
	204.12.100	AEBI TP + VT 98/450 comb. - Upper part rear left	
	205.12.100	AEBI TP + VT 98/450 comb. - Upper part rear right	
3	201.12.200	BUCHER 1800 - Mounting elements	Set incl. fixing
	202.12.200	BUCHER 1800 - Mounting elements	Set without fixing
	203.12.200	BUCHER 1800 - Mounting element front	
	204.12.200	BUCHER 1800 - Mounting element rear right	
	205.12.200	BUCHER 1800 - Mounting element rear left	
4	201.12.250	BUCHER ZENIT - Mounting elements	Set incl. fixing
	202.12.250	BUCHER ZENIT - Mounting elements	Set without fixing
	203.12.250	BUCHER ZENIT - Mounting element front right	
	204.12.250	BUCHER ZENIT - Mounting element front left	
	205.12.250	BUCHER ZENIT - Mounting element rear right	
	206.12.250	BUCHER ZENIT - Mounting element rear left	
5	201.12.300	LINDNER UNITRAC - Mounting elements	Set incl. fixing
	202.12.300	LINDNER UNITRAC - Mounting elements	Set without fixing
	203.12.300	LINDNER UNITRAC - Mounting element front right	
	204.12.300	LINDNER UNITRAC - Mounting element front left	
	205.12.300	LINDNER UNITRAC - Mounting element centre	
	206.12.300	LINDNER UNITRAC - Mounting element rear right	
	207.12.300	LINDNER UNITRAC - Mounting element rear left	
5	201.12.310	LINDNER UNITRAC - (with torsional damper)- Mounting elements	Set incl. Fixing
	202.12.310	LINDNER UNITRAC - (with torsional damper)- Mounting elements	Set without fixing
	203.12.310	LINDNER UNITRAC - (with torsional damper)- Mounting element front right	
	204.12.310	LINDNER UNITRAC - (with torsional damper)- Mounting element front left	
	205.12.300	LINDNER UNITRAC - (with torsional damper)- Mounting element centre	
	206.12.300	LINDNER UNITRAC - (with torsional damper)- Mounting element rear right	
	207.12.300	LINDNER UNITRAC - (with torsional damper)- Mounting element rear left	
6	201.12.320	LINDNER UNITRAC (low) - Mounting elements	Set incl. Fixing
	202.12.320	LINDNER UNITRAC (low) - Mounting elements	Set without fixing
	203.12.320	LINDNER UNITRAC (low) - Mounting element front right	
	204.12.320	LINDNER UNITRAC (low) - Mounting element front left	
	205.12.320	LINDNER UNITRAC (low) - Mounting element centre	
	206.12.320	LINDNER UNITRAC (low) - Mounting element rear right	
	207.12.320	LINDNER UNITRAC (low) - Mounting element rear left	

Mounting elements for truck

Pos.	Order no.	Order text	
7	201.12.330	LINDNER 3500 old - Mounting elements	Set incl. fixing
	202.12.330	LINDNER 3500 old - Mounting elements	Set without fixing
	203.12.330	LINDNER 3500 old - Mounting element	front
	204.12.330	LINDNER 3500 old - Mounting element	centre
	205.12.330	LINDNER 3500 old - Mounting element	rear
8	206.12.330	LINDNER 3500 new (from year 85)	Set incl. fixing
	207.12.330	LINDNER 3500 new (from year 85)	Set without fixing
	208.12.330	LINDNER 3500 new (from year 85)	Mounting element front and centre left
	209.12.330	LINDNER 3500 new (from year 85)	Mounting element front and centre right
	210.12.330	LINDNER 3500 new (from year 85)	Mounting element rear right
	211.12.330	LINDNER 3500 new (from year 85)	Mounting element rear left
9	201.12.400	MULI 30-970 - Mounting elements	Set incl. fixing
	202.12.400	MULI 30-970 - Mounting elements	Set without fixing
	203.12.400	MULI 30-970 - Mounting element front	
	204.12.400	MULI 30-970 - Mounting element rear upper part	
	205.12.400	MULI 30-970 - Screw bracket rear	
10	206.12.400	MULI T8/T9 Rear axle spr. - Mounting elements	Set incl. fixing
	207.12.400	MULI T8/T9 Rear axle spr. - Mounting elements	Set without fixing
	203.12.400	MULI T8/T9 Rear axle spr. - Mounting element front	
	204.12.400	MULI T8/T9 Rear axle spr. - Mounting element rear upper part	
	208.12.400	MULI T8/T9 Rear axle spr. - Screw bracket rear	
11	201.12.450	MULI 40 - Mounting elements	Set incl. fixing
	202.12.450	MULI 40 - Mounting elements	Set without fixing
	203.12.450	MULI 40 - Mounting element front	
	204.12.450	MULI 40 - Mounting element centre	
	205.12.450	MULI 40 - Mounting element rear	
12	201.12.500	RAPID 1750 / LINDNER Lüönd - Mounting elements	Set incl. fixing
	202.12.500	RAPID 1750 / LINDNER Lüönd - Mounting elements	Set without fixing
	203.12.500	RAPID 1750 / LINDNER Lüönd - Mounting element front / centre right	
	204.12.500	RAPID 1750 / LINDNER Lüönd - Mounting elements front / centre left	
	205.12.500	RAPID 1750 / LINDNER Lüönd - Mounting element rear right	
	206.12.500	RAPID 1750 / LINDNER Lüönd - Mounting element rear left	
13	201.12.530	RAPID 1400 - Mounting elements	Set incl. fixing
	202.12.530	RAPID 1400 - Mounting elements	Set without fixing
	203.12.530	RAPID 1400 - Mounting element front	
	204.12.530	RAPID 1400 - Mounting element rear right	
	205.12.530	RAPID 1400 - Mounting element rear left	
14	201.12.560	RAPID 2000-26 - Mounting elements	Set incl. fixing
	202.12.560	RAPID 2000-26 - Mounting elements	Set without fixing
	203.12.560	RAPID 2000-26 - Mounting element front	
	204.12.560	RAPID 2000-26 - Mounting element rear	

Mounting elements for truck

Pos.	Order no.	Order text	
15	201.12.600	SCHILTRAC - Mounting elements	Set incl. fixing
	202.12.600	SCHILTRAC - Mounting elements	Set without fixing
	203.12.600	SCHILTRAC - Mounting element front / centre	left
	204.12.600	SCHILTRAC - Mounting element front / centre	right
	205.12.600	SCHILTRAC - Mounting element	rear
16	201.12.700	SCHILTER 1600 - Mounting elements	Set incl. fixing
	202.12.700	SCHILTER 1600 - Mounting elements	Set without fixing
	203.12.700	SCHILTER 1600 - Mounting element front / centre	
	204.12.700	SCHILTER 1600 - Mounting element	rear
17	201.12.730	SCHILTER 2200 - Mounting elements	Set incl. fixing
	202.12.730	SCHILTER 2200 - Mounting elements	Set without fixing
	203.12.730	SCHILTER 2200 - Mounting element front / centre	
	204.12.730	SCHILTER 2200 - Mounting element	rear
18	201.12.760	SCHILTER 1800 - Mounting elements	Set incl. fixing
	202.12.760	SCHILTER 1800 - Mounting elements	Set without fixing
	203.12.760	SCHILTER 1800 - Mounting element front / centre	
	204.12.760	SCHILTER 1800 - Mounting element	rear
19	201.12.810	Caron Typ C 40/48/52/55/63	Set incl. Fixing
	202.12.810	Caron Typ C 40/48/52/55/64	Set without fixing
	203.12.810	Caron Typ C 40/48/52/55/65	front left
	204.12.810	Caron Typ C 40/48/52/55/66	front right
	205.12.810	Caron Typ C 40/48/52/55/67	centre
	206.12.810	Caron Typ C 40/48/52/55/68	rear right
	207.12.810	Caron Typ C 40/48/52/55/69	rear left
	208.12.810	Caron Typ C (short wheelbase)- Mounting element	rear left
	209.12.810	Caron Typ C (short wheelbase)- Mounting element	rear right
20	201.12.800	CARON Series 900 + CT/CTK/CTM/CTS	Set incl. fixing
	202.12.800	CARON Series 900 + CT/CTK/CTM/CTS	Set without fixing
	203.12.800	CARON Series 900 + CT/CTK/CTM/CTS	front left
	204.12.800	CARON Series 900 + CT/CTK/CTM/CTS	front right
	205.12.800	CARON Series 900 + CT/CTK/CTM/CTS	centre
	206.12.800	CARON Series 900 + CT/CTK/CTM/CTS	rear
30	201.12.030	Counter plate	M16
31	201.12.031	Toothed washer	M16
32	201.12.032	Hexagon screw	M16x35
	201.12.033	Halfen head fixing screw for C-profile	M16x40
	601.04.040	Hexagonal nut M16	M16
	201.12.034	Threaded plate for C-profile	M12

Self-adhesive signs

Pos. Order no. Order text

001.13.001 Lubrication plan mounted model

SCHMIER- UND WARTUNGSPLAN


- Schmiernippel täglich mit Universalfett schmieren
- △ Schmiernippel wöchentlich mit Universalfett schmieren
- Rollenketten wöchentlich mit Kettenöl schmieren
- A Getriebeöl alle 2 Jahre wechseln 0.8L Motorex BF 100
- B Hydrauliköl alle 2 Jahre wechseln 8L Motorex EP 032
- ⊗ Kratzbodenspannung täglich kontrollieren
- ⊕ Rollenketten- und Keilriemenspannung täglich kontrollieren

PLAN DE LUBRIFICATION ET D'ENTRETIEN

- Lubrifier chaque jour le graisseur en utilisant de la graisse universelle
- △ Lubrifier chaque semaine le graisseur en utilisant de la graisse universelle
- Lubrifier tous les semaines les chaînes en utilisant de l'huile pour chaîne
- A Remplacer l'huile d'engrenage tous les 2 ans. Motorex BF 100 0.8l
- B Remplacer l'huile hydraulique tous les 2 ans. Motorex EP 032 8l
- ⊗ Contrôler chaque jour la tension du fond de raclage
- ⊕ Contrôler chaque jour la tension des chaînes et de la courroie trapézoïdale

SCHEMA DI LUBRIFICAZIONE E MANUTENZIONE


- Lubrificare ogni giorno il nipplo ingrassatore con grasso universale
- △ Lubrificare ogni settimana il nipplo ingrassatore con grasso universale
- Lubrificare ogni settimana le catene con olio per catena
- A Sostituire l'olio del cambio ogni 2 anni - 0,8L Motorex BF 100
- B Sostituire l'olio idraulico ogni 2 anni - 8L Motorex BF 032
- ⊗ Controllare ogni giorno la tensione della catena tappeto
- ⊕ Controllare ogni giorno la tensione della catena e della cinghia trapezoidale



Self-adhesive signs

Pos. Order no. Order text


001.13.002 Notice belt tensioner




001.13.003 Notice chain tensioner



001.13.004 Notice scraper floor tension



001.13.005 Lubrication




002.13.010 1x danger, 2x warning




Self-adhesive signs

Pos.	Order no.	Order text
------	-----------	------------


002.13.013	3x danger	
------------	-----------	--




002.13.016	1x warning	
------------	------------	--



002.13.017	3x warning	
------------	------------	--



002.13.020	Max. 600 rpm	
------------	--------------	--



002.13.021	GAFNER large clear	
------------	--------------------	--

002.13.022	vario	
------------	-------	--

002.13.023	roto	
------------	------	--